



Date: July, 2012

Where lead lined doors are hung as active/inactive pairs the normal method of shielding the meeting edge gap is by use of an overlapping wood astragal lined with lead. The astragal (shown below) is typically attached to the inactive leaf on the push side of the opening. Locate one screw in the top and bottom 6" of the astragal with no more 18" between additional screws. Use 1-1/2" long threaded to the head wood screws and pre-drill pilot holes.

