

# ACOUSTIC GASKET SYSTEMS

Installation Instruction 126



Eggers Industries

Date: February, 2015

## Installation of Perimeter Seals: Gasket System P

1. Cut the DHSI Cap Sweep (CS) to match the door width, and install it to the bottom of the door using a sealant such as 100% silicone, small screws, or a combination. Allow the sealant to cure prior to hanging the door.
2. Hang the door and adjust for proper clearances.
3. Prepare the frame by cleaning the jambs and header where the frame seals will be applied.
4. Measure, cut and apply the DHSI 105 gasket on the frame jamb and header, adjacent to the stop. Trim the ends where they meet in the corners such that a good seal will be maintained when the door is in the closed position. The 105 gasket should be full height or width of the opening and should not be spliced.
5. Apply a piece of decibel plug to the bottom of both jambs, adjacent to the 105 gasket. This decibel plug should be sized as required during installation to 1-1/2" wide by the dimension of the undercut.
6. Measure, cut and apply the DHSI Surface Astragal (SA) gasket. This seal should be located adjacent to the pull face of the frame on both jambs and the header. Trim the ends where they meet in the corners such that a good seal will be maintained when the door is in the closed position. The SA gasket should be full height or width of the opening and should not be spliced.



Stile and Rail Doors,  
Door Frames, Plywood  
Veneered Components

Two Rivers Division  
One Eggers Drive  
Two Rivers, WI 54241  
Phone: 920.793.1351  
Fax: 920.793.2958

Flush Doors

Neenah Division  
164 North Lake Street  
Neenah, WI 54956  
Phone: 920.722.6444  
Fax: 920.722.0357

Architectural Veneer Faces,  
Custom Wood Products,  
Plywood

Kentucky Division  
2125 Lake Jericho Road  
Smithfield, KY 40068  
Phone: 502.845.0154  
Fax: 502.849.0444